



## VisiView

For Compatibility: See Software Provider

illumination System	Recognised in VisiView as:	Required VisiView version	USB Control	TTL Control (via external hardware)	Analog Control (via external hardware)	Further software information:	CoolLED Driver
<b>pE-2</b>	precisExcite	3.0.2 or later	Individual Wavelength control	Individual Wavelength control	True Analog	<a href="#">Click for link to VisiView website</a>	Windows XP onwards. 32-bit & 64-bit <a href="#">Click for link to CoolLED driver</a>
<b>pE-300<sup>white</sup></b>	Generic Serial Device	3.0.2 or later	Individual Wavelength control	Global control	N/A		
<b>pE-300<sup>ultra</sup></b>	Generic Serial Device	3.0.2 or later	Individual Wavelength control	Global, Individual and sequential Wavelength control	N/A		
<b>pE-340<sup>fura</sup></b>	Generic Serial Device	3.0.2 or later	Individual Wavelength control	Global, Individual and sequential Wavelength control	N/A		
<b>pE-4000</b>	Generic Serial Device	3.0.2 or later	Individual Wavelength control	Individual Wavelength control	True Analog		