

VisiView					
Illumination System	USB Control	TTL Control (via ViRTE ^x Realtime Experiment Control Device)	Analog Control (via external hardware)	Further software information:	CoolLED Driver
pE-800 Series	Individual channel control	Global, individual and sequential channel control	True Analogue	pE-800 Series guide VisiView information ViRTE^x information	Link to CoolLED driver Windows XP onwards. 32-bit & 64-bit
pE-300 ^{ultra}	Individual channel control	Global, individual and sequential channel control	N/A		
pE-300 ^{white}	Individual channel control	Global control	N/A		
pE-340 ^{fura}	Individual channel control	Global, individual and sequential channel control	N/A		
pE-4000	Individual channel control	Individual channel control	True Analogue		
pE-2 (discontinued)	Individual channel control	Individual channel control	True Analogue		